


MANUAL DE INSTRUCCIONES INSTRUCTIONS MANUAL

COMPROBADOR DE ENCHUFES Y LOCALIZADOR DE PROTECCIONES

KPS-CC820 - SKU: KPSCC820CBINT



KPS



ESPAÑOL

ESP

La función del comprobador de enchufes y localizador de protecciones es detectar el fusible o protección que corresponde al circuito conectado a un enchufe. No volverá a tener dificultades para determinar la protección correspondiente al circuito de alimentación de una toma AC o un punto de iluminación.

Advertencia: Por favor tome precauciones extremas al utilizar el instrumento con un elevado arco eléctrico de las protecciones. No lo utilice si el voltaje es superior a 120V/230V AC. Puede encender la linterna en entornos oscuros.

Características

- Encuentra de forma rápida y automática la protección o fusible correctos.
- Identifica rápida y fácilmente el estado del cableado del enchufe.
- Funciona en circuitos de 220V AC
- Temperatura de funcionamiento: 0-50°C

Funcionamiento: Localización de la protección o fusible

- Sitúe el interruptor del comprobador de enchufes en la posición izquierda.
- Conecte el comprobador en el enchufe.
- Diríjase al cuadro de protecciones de la instalación.
- Encienda el receptor. La luz roja se encenderá.
- Coloque la punta del receptor sobre el dispositivo de protección o fusible.
- Deslice la punta del receptor a lo largo de cada dispositivo de protección. El receptor emitirá pitidos de forma continua en función de la fuerza de la señal recibida.
- Deslice de nuevo el receptor en cada protección. A la tercera vez, el receptor emitirá un pitido, la luz roja se apagará y la luz verde se encenderá solo en el dispositivo de protección que alimenta al enchufe seleccionado.
- Abra el dispositivo de protección y compruebe que la luz LED en el comprobador de enchufes está apagada para confirmar que el interruptor o fusible seleccionado es el correcto.

Comprobación del enchufe

- Sitúe el interruptor del comprobador de enchufes en la posición derecha.
- Por favor, observe las indicaciones mostradas en la etiqueta del comprobador de enchufes.


Mantenimiento

- Mantenga limpio los dispositivos con un trapo húmedo.
- Cuando el LED amarillo esté encendido en el receptor, por favor desatornille y retire la tapa y coloque una nueva pila de 9V para que el receptor funcione correctamente.

MANUAL DE INSTRUCCIONES INSTRUCTIONS MANUAL

CIRCUIT BREAKER FINDER SOCKET TESTER INSTRUCTION

KPS-CC820 - SKU: KPSCC820CBINT



KPS



ENGLISH

ENG

The task of Circuit Breaker Finder/Socket Tester (KPSCC820) is to find the correct breaker or fuse and test the socket. You will have no more trouble locating the correct circuit breaker supplying power to an AC outlet or lighting fixture.

WARNING: Please caution extremely when use the KPSCC820 in the gigantic circuit breaker ark. Don't use when voltage more than 120V/230V AC. You can turn on the flashlight in the dark surroundings.

Features

- Automatically and quickly finds correct breaker or fuse.
- Quickly and easily identifies conditions of circuit socket.
- MS5902-Tx Works on 220V AC, MS5902-TB Works on 110V AC
- Operating temperature: 0 - 50°C

Operation: Locating a Circuit Breaker or Fuse

- Keep the pillar at left on the KPS-CC820
- Plug the KPS-CC820 into the receptacle. If there is a candescent light fixture, please install a socket adapter before make sure the switch is OFF. then plug the KPSCC820 into the socket adapter, turn the switch on at one time. (Socket adapter need purchase additional)
- Go to the circuit breaker panel box.
- Turn the KPS-CC820 on, the red LED is light.
- Place the chapter of the KPS-CC820 directly onto the circuit breaker or fuse.
- Slide the chapter of the KPS-CC820 down each breaker along both sides of the panel. Then the KPS-CC820 will beep frequently as it denotes the relative signal strength.
- Move the KPS-CC820 down each breaker once more. On the third pass, the KPS-CC820 will beep, the red LED will quench and the green LED will light only at the circuit Breaker powering the KPS-CC820.
- Push the breaker off and check that the LED on the KPSCC820 in the outlet is off to confirm you have found the correct breaker or fuse.

Test Socket

- Keep the pillar at right on the KPS-CC820.
- Please contrast distinguish nameplate on the KPS-CC820.

Maintenance

- Keep clean with a dry cloth.
- When the yellow LED is light on the KPS-CC820, please unscrew and remove cover, insert new 9V battery so as to the KPS-CC820 is well-balanced.

APAC: **MGL GLOBAL SOLUTIONS LTD**
Taipei, Taiwan.
info.apac@mgl-intl.com

EMEA: **MGL EUMAN S.L.**
Asturias, Spain.
info.emea@mgl-intl.com

AMERICAS: **MGL AMERICA, LLC.**
US East Coast: Charlotte, North Carolina.
US West Coast: Brea, California.
info.na@mgl-intl.com

www.mgl-intl.com

Ver el manual
de instrucciones
completo



See the full
instruction manual

